

DRIVER INSTALLATION

To install the virtual driver on your PC, follow the steps outlined below.

Step 1: Click on the web browser, then paste the following link into the address VCP Drivers - FTDI (ftdichip.com).

Step 2: Click on "setup executable", the option initiate download process directly.

Driver installation Link: <https://ftdichip.com/drivers/vcp-drivers/>

| Operating System | Release Date | Processor Architecture | | | | | | | Comments |
|------------------------|--------------|----------------------------|----------------------------|------------------------|--------------------------------|--------|--------|-----|--|
| | | X86 (32-Bit) | X64 (64-Bit) | PPC | ARM | MIPSII | MIPSIV | SH4 | |
| Windows (Desktop)* | 2021-07-15 | 2.12.35.d | 2.12.35.f | --- | 2.12.35.45**** | --- | --- | --- | WHQL Certified. Includes VCP and C2XX. Available as a VSIX package . Please read the license.html and installation guides . |
| Windows (Universal)*** | 2021-01-12 | 2.12.35.dU | 2.12.35.fU | --- | --- | --- | --- | --- | WHQL Certified. Includes VCP and C2XX. |
| Linux | --- | --- | --- | --- | --- | --- | --- | --- | All FTDI devices are supported in Ubuntu 11.10, kernel 3.0.0-19. Refer to This file if you need a custom VCP VID/PID in Linux. VCP drivers are integrated into the kernel. |
| Mac OS X 10.5 to 10.8 | 2012-05-10 | 2.2.18 | 2.2.16 | 2.2.18 | --- | --- | --- | --- | Refer to This file if you need a custom VCP VID/PID in MAC OS. |
| Mac OS X 10.9 to 10.13 | 2019-12-24 | --- | 2.4.2 | --- | --- | --- | --- | --- | This driver is signed by Apple. |
| Mac OS 11.0-11.4 | 2019-12-24 | --- | 2.4.1 | --- | --- | --- | --- | --- | This driver is signed by Apple. |

Step 3: Let's Start the installation Process, Read and Agree terms and condition, then click on finish.



Driver installation has been successfully completed.